



Pierścień centrujący

Locating ring

PCA



h	D	H	NR KAT.
4	100	8	PCA-100080
7		11	PCA-100110
9		13	PCA-100130
11		15	PCA-100150
12.5		16.5	PCA-100165
4		110	8
7	11		PCA-110110
4	12		PCA-110120
9	13		PCA-110130
11	15		PCA-110150
12.5	16.5		PCA-110165
4	120	8	PCA-120080
7		11	PCA-120110
4		12	PCA-120120
9		13	PCA-120130
11		15	PCA-120150
12.5		16.5	PCA-120165
4	125	8	PCA-125080
7		11	PCA-125110
4		12	PCA-125120
9		13	PCA-125130
11		15	PCA-125150
12.5		16.5	PCA-125165

Pierścień centrujący

Locating ring


PCA

h	D	H	NR KAT.
4	130	12	PCA-130120
	140		PCA-140120
	150		PCA-150120
7	160	8	PCA-160080
4		11	PCA-160110
9		12	PCA-160120
11		13	PCA-160130
12.5		15	PCA-160150
4		16.5	PCA-160165
7		175	8
4	11		PCA-175110
9	12		PCA-175120
11	13		PCA-175130
12.5	15		PCA-175150
4	16.5		PCA-175165
4	180		12
4	200	PCA-200120	
4	250	PCA-250120	

Pierścień centrujący

Locating ring

PCA





d	h	D	H	NR KAT.
36	4	60	8	PCA-060080
26	7		11	PCA-060110
	9		13	PCA-060130
36	4	80	8	PCA-080080
26	7		11	PCA-080110
	9		13	PCA-080130

Pierścień centrujący

Locating ring

PCA



H	NR KAT.
8	PCA-090080
11	PCA-090110
13	PCA-090130
15	PCA-090150
16.5	PCA-090165